



INSTRUCTION MANUAL

STREAMLINE

Product:
Streamrack

Code:
VG-RS126



English

INSTR-VG-RS126


Safety Regulations

Warnings


- Sharp edges
- Moving Components
- Pinch Risks
- Weight when moving
- Fall Risk
- Must be tied down in van

Required PPE

Use personal protective equipment to avoid personal injury:



Protective Gloves



Protective Footwear

Additional protective equipment such as a dust mask, non-skid safety shoes, hard hat or hearing protection may be required depending on the safety regulations in the operator surroundings.

Use

General

- Do not exceed a weight of 25kg when loading each shelf.
- Large objects should be secured in place during transit to prevent damage to the racking unit.
- Do not climb on racking unit.

Recommended Fixing Method

- Note: Extra caution should be taken when drilling holes into a vehicle. Take care not to damage the bodywork or vital elements of the vehicle when drilling.
- Position the vehicle in the desired location in the vehicle, if this is over a wheel arch, the height configuration of the racking will need to be changed (see below).
- Once positioned, measure the location of the floor brackets from the back and side of the van. use these measurements to then check that the underside of the van is clear from obstruction for drilling.
- Mark the hole centres of the fixing points on the floor brackets, three holes should be marked on either side, with at least an additional 3 along the long side of the unit. Move the racking to drill 8mm dia. holes in the correct positions.
- Replace the racking unit in position and secure using M6x50 bolts and washers, with M6 nylon nuts and washers fastening the bolts from the under side of the van.
- The back panel of the racking should be securely fixed to the wall panels of the van. It is recommended that all fixings should be to the inner skin of the vehicle, not the wooden lining. Care should be taken that there is enough space between the inner and outer skins to not damage the bodywork of the vehicle.
- The shelf units have dedicated holes which can be used to secure them to the walls of the vehicle. Ensure that the fixing points are free from obstruction before drilling.
- Use suitable length M6 bolts with M6 washers and nylon nuts to secure the racking unit.

Height Configuration

- The Streamrack is supplied in the low height configuration. It can easily be changed to give additional height, ideal for being fitted over wheel arches.
- To change the height of the legs, first remove the 4x bolts holding the legs onto the body of the racking on one side. Each leg has 2x bolts, fitted into clinch nuts on the shelf unit.
- Once the bolts are removed, slide the legs down until the other set of hole's line up with the clinch nuts on the shelves.
- Re-fasten the bolts into the clinch nuts, ensure they are tight but take care not to over-tighten as this may damage the unit.
- Repeat this for the legs on the opposite side.

Maintenance

General

- If water is spilled onto the device, wipe it clean with a dry, lint free, non-abrasive cloth to prolong life
- Regularly check for excessive wear and tear, discontinue use if there is damage to any fixings or fastenings on the unit.

Streamline® Warranty

The warranty on all Machines and Equipment is for 1 year (12-months) from RECORDED DATE OF PURCHASE.

THIS WARRANTY EXCLUDES NORMAL MAINTENANCE ITEMS, including but not limited to HOSES, FILTERS, O-RINGS, DIAPHRAGMS, VALVES, GASKETS, CARBON BRUSHES and damage to motors and other components as a result of failure to replace normal maintenance items. THIS LIST IS NOT EXHAUSTIVE.

If Streamline® receives notice of such defects during the warranty period, Streamline® will either, at its opinion, repair or replace components which prove to be defective.

Replacement parts will only be supplied under warranty, upon the inspection and approval of the defective parts by Streamline®.

Should it be necessary to supply replacement parts before the opportunity to inspect, these will be charged at current prices and credit will only be issued upon subsequent inspection and warranty approval by Streamline®.

The customer is responsible for the cost of return of the defective part. If warranty is approved, Streamline® will pay for the cost of the repaired or replacement part.

This warranty excludes the following conditions and circumstances which are at the discretion of Streamline®:

Wear and tear, misuse, abuse improper maintenance, frost damage, the use of chemicals other than those supplied or approved by Streamline®, improper installation or repair, unauthorised modification, incidental or consequential costs, loss or damage, service, labour or third party charges, the cost of returning defective parts to Streamline®.

This warranty constitutes the exclusive remedy of any purchaser of a Streamline® unit and is in lieu of all other warranties, express or implied, including without limitation any implied warranty of merchantability or fitness for use, to the fullest extent permitted by law. In no event shall any implied warranty of merchantability or fitness for use exceed the term of the applicable warranty stated above and Streamline® shall have no other obligation or liability.

Important

Unfortunately these rights cannot be transferred to a third party.





Hamilton House, 8 Fairfax Road,
Heathfield Industrial Estate,
Newton Abbot
Devon, TQ12 6UD
United Kingdom

Telephone: +44 (0) 1626 830 830

Email: sales@streamline.systems

Visit: www.streamline.systems

INSTR-VG-RS126